

Documentation

HiPath

OpenStage T RNDIS Driver

Installation Guide



Communication for the open minded

Siemens Enterprise Communications
www.siemens.com/open

SIEMENS

Connecting OpenStage T and OpenStage Manager

This manual explains how to install the driver software and describes the required configuration to operate an OpenStage 60 T or OpenStage 80 T with OpenStage Manager PC software.

Requirements

- An operational OpenStage 60/80 T.
- A USB cable.
- The "OpenStageRNDIS V1 Rx.x.x Install.exe" driver software.
- The uninstalled Software OpenStage Manager.
- OpenStage 60/80 T in operation.
- **IMPORTANT: No USB connection from the phone to the PC.**

Notes

USB Port

Following installation the PC and OpenStage 60/80 T can only be connected using exactly the same port the phone was connected to during installation. If the phone is connected to a different USB port, the PC cannot establish a connection.


As long as the OpenStage Manager is not open, you can disconnect or reconnect the USB plug from the USB port.

MS Windows 2000


If installing the the driver software under MS Windows 2000 a message might appear asking whether you want to reboot the system. In this case cancel the message as it is not necessary to reboot the system.

How to Install

1. Launch the **OpenStageRNDIS V1 Rx.x.x Install.exe** file.
The following security warning appears.




2. Click **Run**.
The installation wizard launches.




3. Ensure that the OpenStage 60/80 T and PC are not yet connected via USB cable.
Then click **Next**.

A new window opens.



4. Click **Next**.

You are then requested to read and accept the license agreement.



5. Click **I accept this EULA** to accept the license agreement.

6. Click **Next**.


The following installation steps are displayed.

Often an MS Windows warning appears immediately afterwards.



7. Click **Continue Setup**.

A message confirms proper installation.




8. Click **Finish**.


The following notification window appears.



9. Firstly connect the OpenStage 60/80 T to the PC using the USB cable. Do not yet click OK. We'll come back to this later.



The operating system has detected the OpenStage 60/80. When connected, the hardware installation wizard is launched automatically. The installation can take several minutes.



10. Click **Yes, just this time** to select this function and then click **Next**.



11. Click **Install the software automatically** to select this function and then click **Next**.

The following standard warning appears.



12. Click **Continue Setup**.

The wizard is finished installing.



13. Click **Finish**.


Some settings are then made automatically. This can take a moment.

The wizard closes and the following window can be seen again.



14. Click **OK**.

The installation wizard confirms the installation was successful.



15. Click **Finish**.

The driver is now installed.

Reference No.: A31003-S2000-J105-1-7631

© Siemens Enterprise
Communications GmbH & Co. KG
Hofmannstr. 51,
D-81359 München

Communication for the open minded

Siemens Enterprise Communications
www.siemens.com/open

The information provided in this document contains merely general descriptions or characteristics of performance which in case of actual use do not always apply as described or which may change as a result of further development of the products. An obligation to provide the respective characteristics shall only exist if expressly agreed in the terms of contract. Subject to availability. Right of modification reserved. The trademarks used are owned by Siemens Enterprise Communications GmbH & Co. KG or their respective owners.